


! UNITS CONNECTION IN PARALLEL
(No units limit)




Parallel
Connection


CONNECTION BOX

WATER OR UNHEATED


1. Open the connection box:



2. Connect the cables at the electrical element as the picture shows:



! UNITS CONNECTION IN SERIAL
(Maximum 9 Fans)



Serial
Connection